

alert bulletin

AB 008 2018

Truck and Trailer Roll Away


What Happened:

Whilst collecting a loaded trailer from a customers trailer park, the tractor and truck combination rolled forwards and came to a stop by hitting the side of another waiting truck causing damage to the door.

Luckily there were no injuries..... This time!

Findings:

- The driver had <u>not</u> checked the trailer park brake had been applied as part of his pre-coupling checks.
- The driver had <u>forgotten</u> to apply his truck handbrake
- The truck and trailer combination rolled forwards as the driver was connecting his lines and winding up the trailer legs.



Recommendations:

- ✓ Before exiting the tractor unit, the driver must always apply the tractor unit park brake switch of the engine and remove the ignition keys.
- ✓ Tractor units should be fitted with audible alarms to warn the driver that the
 tractor unit park brake has not been applied when exiting the cab. The alarm must
 operate regardless of ignition key state
- ✓ Trailer park brakes must be applied on all uncoupled trailers.

 <u>Disconnecting the red air line does not automatically engage the trailer park brake!</u>

 The trailer park brake must be activated separately by pulling on!

Further guidance on safe coupling and uncoupling of vehicles is available at http://www.hse.gov.uk/workplacetransport/information/coupling.htm

the sense of logistics